


背板功能介绍



- ① POWER指示灯
- ② SIG A(信号)指示灯
- ③ SIG B(信号)指示灯
- ④ CLIP指示灯
- ⑤ PROTECT指示灯
- ⑥ FRONT LED开关
- ⑦ LINE/MIC开关
- ⑧ INPUTS插口(MIC/LINE A)
- ⑨ OUTPUTS插口(OUT A)
- ⑩ INPUTS插口(LINE B)
- ⑪ OUTPUTS插口(MIX OUT)
- ⑫ INPUTS插口(AUX)
- ⑬ INPUTS插口(LINE IN)
- ⑭ OUTPUTS插口(LINE OUT)
- ⑮ GAIN A 增益控制旋钮
- ⑯ GAIN B 增益控制旋钮
- ⑰ 预设选择开关
- ⑱ USB端口
- ⑲ 极性选择开关
- ⑳ 电源开关
- ㉑ AC INPUT电源插座

DSP

MAIN: When EA5 used as PA

SPEECH: When EA5 used for speech

W/SUB: When EA5 used with subwoofer

INPUT CONNECTOR PINS				DSP	
AUX	POS	NEG	FL	MAIN	When EA 6 used as PA
SIG A	P2	P3	FR	SPEECH	When EA 6 used for speech
SIG B	TIP	RING	SL	W/SUB	When EA 6 used with subwoofer
			BARREL		

CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN

WARNING! RISK OF HAZARDOUS ENERGY ONLY MUST BE ENLIGHTENED AND CORRECTLY FORGED. TO REDUCE RISK OF ELECTRIC SHOCK OR FIRE, DO NOT EXPOSE TO MOISTURE. NO USER SERVICEABLE PARTS INSIDE.